

HARDWOOD PRE-DELIVERY CHECKLIST



To help ensure that your Hardwood Delivery goes according to plan and warranties are not voided, please keep in mind the following:

ENVIRONMENTAL CONDITIONS

- Make sure that the HVAC and humidification/ Dehumidification systems have been operating continuously for at least 5 working days before delivery. Temporary systems that mimic normal living (occupied) conditions can enable the installation to proceed until the permanent heating and/or air conditioning system is fully operational. Temperature should be maintained between 69 F - to 73 F and Relative Humidity between 40% to 45%
- All wet trades should have completed their work.

JOBSITE/ AREA CONDITIONS

- Unless otherwise noted, all subfloors must be sound and flat 1/4" in a 10 ft radius.
- Make sure that the jobsite/ area is easily accessible and clean of obstacles and debris.
- Electricity must be readily available.
- For installations over crawlspaces, all dirt must be covered, and adequate ventilation provided as per Code.

MATERIAL RELATED CONDITIONS

- Inspect all materials carefully after delivery.

ADDITIONAL

- Please let us know within 72 hrs of delivery if the schedule needs to be adjusted.
- Be aware that occasionally, during Delivery, there are minor scuffing or chipping of painted surfaces such as molding, walls, baseboards, etc. Be prepared to do minor "touch ups".
- If you have additional questions, please let us know.
- One of our representatives will be onsite monitoring the Moisture Content of the Hardwood and the Subfloors (where applicable) as well as the Relative Humidity and Temperature for Quality Control purposes before installation.